

Fire Polishing Glass Tubing/Rods

Hold the end of the tube to be fire polished in the hot part of a Bunsen burner flame (tip of the inner cone). Rotate the glass until it becomes yellow, begins to melt, and is rounded. *Excessive heating will cause the tube to become closed.*

Remove from the flame and cool on a ceramic plate or wire gauze.

